



Gestures in Android

Download class materials from
university.xamarin.com

Information in this document is subject to change without notice. The example companies, organizations, products, people, and events depicted herein are fictitious. No association with any real company, organization, product, person or event is intended or should be inferred. Complying with all applicable copyright laws is the responsibility of the user.

Microsoft or Xamarin may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any license agreement from Microsoft or Xamarin, the furnishing of this document does not give you any license to these patents, trademarks, or other intellectual property.


© 2014-2017 Xamarin Inc., Microsoft. All rights reserved.

Xamarin, MonoTouch, MonoDroid, Xamarin.iOS, Xamarin.Android, Xamarin Studio, and Visual Studio are either registered trademarks or trademarks of Microsoft in the U.S.A. and/or other countries.

Other product and company names herein may be the trademarks of their respective owners.

Objectives

1. Utilize built-in gestures
2. Create custom gestures programmatically






Utilize built-in gestures



Xamarin
University


Tasks

1. Define gestures
2. Implement the gesture detector
3. Handle gestures
4. Discuss scaling and double tap gestures



What is a gesture?


- ❖ A gesture is a hand-drawn shape on the touch screen
- ❖ Gestures are detected by an app from a sequence of points




Interpreted as: **OnFling**

Built-in gestures


- ❖ Android supports several built-in gestures



OnDown
Down




OnShowPress
Down, hold (~100ms)



OnLongPress
Down, hold (~600ms)


Built-in gestures

- ❖ Android supports several built-in gestures




OnFling

Down, move, up



OnScroll

Move



OnSingleTapUp


Down, up

Built-in gestures

- ❖ Android supports several built-in gestures



OnDoubleTap
Down, up, down



OnScale
Two fingers down,
move together/apart

Demonstration


GestureListener



Xamarin
University

Interpreting a gesture

- ❖ Android *gesture detectors* interpret a sequence of **MotionEvent**s as a gesture



Two types of Gesture Detectors

- ❖ Android provides two built-in Gesture Detectors



GestureDetector


Reports most common gestures

ScaleGestureDetector

Reports scale gesture

Listener interface pattern

- ❖ The gesture detectors use a listener interface pattern to report when gestures have been detected



Depending on the gesture you are checking for, you will use one of three gesture listener interfaces with their corresponding **GestureDetector**

IGestureRecognizer

- ❖ The **IGestureRecognizer** defines the callback methods for six of the most common gestures



IONDoubleTapGestureRecognizer

- ❖ Implement the **IONDoubleTapGestureRecognizer** for double tap gestures



IScaleGestureListener

- ❖ The **IScaleGestureListener** is used to listen for scaling/pinch and zoom gestures



For scaling gestures implement the **ScaleGestureDetector** with the **IScaleGestureListener**

Flash Quiz

Flash Quiz

- ① Which gesture detector object is used with **IONDoubleTapGestureListener**?
- a) DoubleTapGestureDetector
 - b) GestureDetector
 - c) ScaleGestureDetector

Flash Quiz

- ① Which gesture detector object is used with **IONDoubleTapGestureListener**?
- a) DoubleTapGestureDetector
 - b) GestureDetector
 - c) ScaleGestureDetector

Flash Quiz

- ② The gesture detector is responsible for _____
- a) forwarding the motion events
 - b) generating the motion events
 - c) interpreting the motion events

Flash Quiz


- ② The gesture detector is responsible for _____
- a) forwarding the motion events
 - b) generating the motion events
 - c) interpreting the motion events

Listen for gestures

- ❖ To create a gesture detector you must implement one of the gesture listener interfaces

```
public class MainActivity : Activity, IOnGestureListener
{
    ...
}
```

The interface is often implemented on an Activity



IGestureRecognizer methods

- ❖ **IGestureRecognizer** requires 6 methods; 1 for each of it's supported gestures

```
bool OnDown (MotionEvent e) { ... }  
bool OnFling (MotionEvent e) { ... }  
void OnLongPress (MotionEvent e) { ... }  
bool OnScroll (MotionEvent e) { ... }  
void OnShowPress (MotionEvent e) { ... }  
bool OnSingleTapUp (MotionEvent e) { ... }
```

Instantiate the Gesture Detector


- ❖ Instantiate the Gesture Detector and pass the gesture listener as a parameter in the constructor

```
protected override void OnCreate (Bundle bundle)
{
    ...
    gestureDetector = new GestureDetector (context: this, listener: this);
}
```

A context and a listener are
required by the Gesture Detector

Forward the MotionEvent

- ❖ It is your responsibility to send the **MotionEvent**s to the gesture detector



Example: Tap to select

- ❖ When **OnTouchEvent** called - pass the **MotionEvent** to the gesture detector

```
public override OnTouchEvent (MotionEvent e)
{
    gestureDetector.OnTouchEvent(e);

    var x = e.GetX();
    var y = e.GetY();
    ...
}
```



Individual Exercise

Create an app that utilizes the scrolling gesture

Double tap listener

- ❖ The **IONDoubleTapListener** is implemented similarly to **IONGestureListener** and is used with the **GestureDetector** class

```
bool OnDoubleTap (MotionEvent e) { ... }  
  
bool OnDoubleTapEvent (MotionEvent e) { ... }  
  
bool OnSingleTapConfirmed (MotionEvent e) { ... }
```

SetOnDoubleTapListener method

- ❖ **GestureDetector** reports double tap gestures to a separate listener object

```
protected override void OnCreate (Bundle bundle)
{
    ...
    gestureDetector = new GestureDetector (context: this, listener: this);
    gestureDetector.SetOnDoubleTapListener (listener: this);
}
```



DoubleTapListener is registered using a set method, *not* the constructor

Three steps to implement scaling

- ❖ Scaling is handled similarly to other gestures but uses the **IONScaleListener** and **ScaleGestureDetector**

Implement
IONScaleListener

Instantiate the
ScaleGestureDetector

Forward **MotionEvent**s to
the **ScaleGestureDetector**

Implement the scale gesture listener

- ❖ The **IONScaleGestureListener** receives scaling events

```
public class MainActivity : Activity, IONScaleGestureListener
{
    ...
}
```

```
protected override void OnCreate (Bundle bundle)
{
    ...
    scaleDetector = new ScaleGestureDetector (this, this);
}
```



Implement IOnScaleGestureListener

- ❖ The methods for the scaling interface are then applied

```
bool OnScale (MotionEvent e) { ... }  
  
bool OnScaleBegin (MotionEvent e) { ... }  
  
void OnScaleEnd (MotionEvent e) { ... }
```


Forward the motion event

- ❖ When listening for scaling gestures you will pass the **MotionEvent** to the **ScaleGestureDetector**

```
public override bool OnTouchEvent (MotionEvent e)
{
    scaleGestureDetector.OnTouchEvent (e);


    return true;
}
```

Individual Exercise

Utilize the scaling gesture

Summary

1. Define gestures
2. Implement the gesture detector
3. Handle gestures
4. Discuss scaling and double tap gestures




Create custom gestures programmatically



Xamarin
University


Tasks

1. Categorize gestures
2. Build a detector for a custom gesture
3. Define a gesture listener interface




What is a custom gesture?

- ❖ A *custom gesture* is a gesture that is not directly supported by Android




Android does not have a built-in detector for the rotation gesture




You can define app-specific gestures, e.g. draw a lightning bolt to perform a game move

Gesture types

- ❖ Gestures are split into two categories based on whether they have a finite path



Continuous gestures can be performed indefinitely



Discrete gestures have a fixed path

Creation overview

- ❖ There are two steps to creating a custom gesture programmatically

Code a gesture detector

Define a listener interface



Creating a custom gesture programmatically lets you support both continuous and discrete gestures

Define a listener interface

- ❖ You define a listener interface that clients implement to be notified when the gesture is detected

```
public interface IOnRotationGestureListener
{
    void OnRotateStarted (MotionEvent event);
    void OnRotate (MotionEvent event, float angle);
    void OnRotateCompleted (MotionEvent event);
}
```

Code a gesture detector

- ❖ Custom gestures typically follow the standard **GestureDetector** pattern

```
public class RotationGestureDetector
{ ...
    public RotationGestureDetector (IOnRotationGestureListener listener)
    {
        ...
    }
    public bool OnTouchEvent (MotionEvent e)
    {
        ...
    }
}
```

Client registers
a listener

The method is named
OnTouchEvent as a
matter of convention

Client code forwards
the **MotionEvent**


Implementation [concept]

- ❖ The gesture detector *analyzes* the motion events that it receives, *determines* when the gesture has occurred, and *notifies* the listener

Finger 1 down




Finger 2 down




Move



Finger up



Both fingers up



Implementation [code]

❖ Gesture detection and reporting typically done in **OnTouchEvent**

```
public bool OnTouchEvent (MotionEvent e)
{
    switch (e.ActionMasked)
    {
        case MotionEventActions.Down:           /* first finger down */ break;
        case MotionEventActions.PointerDown:     /* second finger down */ break;
        case MotionEventActions.Move:            /* rotation occurring */ break;
        case MotionEventActions.PointerUp:       /* one finger up */ break;
        case MotionEventActions.Up:              /* second finger up */ break;
    }
}
```

Forward the MotionEvent

- ❖ The client is responsible for forwarding **MotionEvent** to the custom gesture detector

```
public class MyActivity : Activity
{
    public override bool OnTouchEvent (MotionEvent e)
    {
        rotationGestureDetector.OnTouchEvent (e);
        return true;
    }
}
```

Flash Quiz

Flash Quiz

- ① Discrete gestures
 - a) have a defined beginning and end
 - b) have no set end point
 - c) interpret motion events

Flash Quiz

- ① Discrete gestures
 - a) have a defined beginning and end
 - b) have no set end point
 - c) interpret motion events

Flash Quiz

- ② When creating a custom gesture you must follow the patterns the APIs used for **GestureDetector**
- a) True
 - b) False

Flash Quiz

- ② When creating a custom gesture you must follow the patterns the APIs used for **GestureDetector**
- a) True
 - b) False

Individual Exercise


Build a rotation gesture



Xamarin
University


Android Gestures Builder

- ❖ Android provides the Gestures Builder app to help you build discrete gestures




Build a discrete gesture

- ❖ Building a discrete gesture is as easy as tapping on “Add gesture”, naming it, drawing it on the device and tapping “Done”



Use the gestures


- ❖ Using the gestures created by the Gestures Builder application requires several steps:
 - Export the gestures binary from your Android device
 - Add it to the Resources -> Raw folder
 - Load it into a **GestureLibrary** object
 - Add a **GestureOverlayView** to your application
 - Use the **GestureLibrary** to detect gestures performed on the View



Check the lighting lectures section of Xam U website for more information on using gestures created in the Gestures Builder application

Summary

1. Categorize gestures
2. Build a detector for a custom gesture
3. Define a gesture listener interface



Thank You!

Please complete the class survey in your profile:
university.xamarin.com/profile

